




Spring Clamp hydraulic declamping


Description

Belleville springs are used to exert the clamping force. Hydraulic pressure is used to overpower springs to de-clamp the job. Two versions are available

- 1) Spring push & hydraulic pull,
- 2) Spring pull & hydraulic push. Force available is from 500 kg to 10 tons. Stroke available is 4 to 6 mm. These cylinders are made as per the customers needs.



**Spring pull
Hydraulic push**



**Spring push
Hydraulic pull**